

Instructions: RV Air Conditioner Cover

CAUTION:

Never operate your air conditioner with your cover over it. You could damage your air conditioner.

CAUTION:

This cover is for storage use only, not for use while you are driving or transporting your RV. Use while driving will invalidate your warranty.

Installation

1. Cover or tape any sharp edges on the air conditioner that could wear against your cover.

2. Slip your cover over the top of your air conditioner. Tighten the draw cord at the front of your cover to secure the cover bottom tightly to your air conditioner.

Tie off the cord and be sure your cover is on tight so that wind cannot blow it off.

Care and Storage

Spot clean with water, a mild soap and a sponge. Don't use abrasive cleaners or brushes.

Never store a wet cover in a confined area as the cover can be damaged by mildew.

Three Year Limited Warranty

If this cover fails due to a defect in workmanship and materials within three years from the date of purchase, Classic Accessories will repair or replace it free of charge.

Never operate your air conditioner while your RV Air Conditioner Cover is on it. This warranty does not cover any damage to your air conditioner.

Trailering or transporting your RV with your cover on will invalidate your warranty.



This warranty gives you specific rights and you may also have other rights which vary from state to state.



Classic Accessories, Inc.
Kent, WA, USA 98032
www.classicaccessories.com

©2007

77410 77420 77430 77400 77440 07cR59_014